

持込用電源盤(下手)

C型60A ×2
 C型30A ×2
 C型20A ×2
 平行15A ×2
 1Φ3W 3P400AF/300AT
 (カムロックコネクター出し)

持込用電源盤(上手)

C型60A ×2
 C型30A ×2
 C型20A ×2
 平行15A ×2
 1Φ3W 3P400AF/300AT
 (カムロックコネクター出し)

舞台用下手袖集中コンセント盤架

C型30A ×6
 平行15A ×2

舞台用上手袖集中コンセント盤架



C型30A ×6
 平行15A ×2







C型60A × 各2



C型60A × 各2

客席ブースコンセント盤

C型30A ×1
 平行15A ×2



-  → 音響用電源盤
-  → 照明用電源盤
-  → C型60Aコンセント
-  → 1L-3
-  → 2L-4
-  → 3L-4



- →1L-1
- →2L-1